料号：1405000433
品名：中性说明书（英语、中文、荷兰语、法语、德语、意大利语、西班牙语、波兰语、瑞典语、韩语、日语、葡萄牙语）
尺寸：100*120mm
材质：105g双铜纸
折叠方式：骑马订56P
印刷方式：单黑印刷
备注：1PC/台，此页不算

Mini PC

User Manual
用户手册
Handleiding
Manuel de l'Utilisateur
Benutzerhandbuch
Manuale d'uso
Instrukcja obsługi
Manual de usuario
Användarmanual
사용자 설명서
ユーザーマニュアル
Manual do utilizador

Contents

English ---- 01-04
中文 ---- 05-08
Nederlands ---- 09-12
Français ---- 13-16
Deutsch ---- 17-20
Italiano ---- 21-24
Polski ---- 25-28
Español ---- 29-32
Svenska ---- 33-36
한국어 ---- 37-40
日本語 ---- 41-44
Português ---- 45-48

英文

English

User Guide
Dear User: Thank you for using this product. For your safety and benefit, please read this product manual and all the accompanying materials carefully before using the product!


Disclaimer
• Please use the original power supply. For any problems or faults caused by any third-party adapter, the company will not be responsible.
• Users can use music, videos, pictures and software provided by third parties. However, for copyright issues or software malfunctions, we will not be responsible.
• If there is a malfunction, the company will strictly abide by the warranty terms; however, for property losses caused by usage, the company will not be responsible.
• The software pre-installed in the device can be used directly. Whether or not this software is deleted, it will not affect the machine. This situation does not belong to a quality problem.
• The company reserves the right to improve the product. If there are any changes in product specifications and design, it will not be notified separately! Please refer to the actual product.
• Do not disassemble the product by yourself. If the product is damaged due to external physical or chemical damage, which is not caused by the product's own quality problem, the company will not bear any compensation responsibility.

Notes for Attention
• When performing operations that may cause file damage or loss, be extremely careful.
• During the use of a microcomputer, pay attention to virus protection and try to use a virus firewall.
• If the microcomputer is not used for a long time, turn it off and disconnect the power supply.
• Do not frequently turn on and off the microcomputer for short periods of time. It is recommended to leave at least 60 seconds between each power-on.
• Pay attention to moisture prevention and keep the usage environment clean and hygienic. If there is dust on the main unit, use a dry soft cloth to wipe it.
• Avoid direct exposure to strong light on the microcomputer and do not get close to strong magnetic fields.
• Do not spill water, food, or other liquids onto the computer. Do not forcefully pull data cables, power cables, etc.

Operating Conditions:
• Temperature: 0 - 40°C / 32 - 104°F (If there is a conflict between the temperature range and the manual, please refer to the manual.)
• Humidity: 20 - 80% RH.
• Altitude: 0 - 2000 meters.

Safety Warning
• This product is equipped with a button battery. Do not disassemble, impact, squeeze or throw it into fire.
• Do not place this product in a high-temperature environment.
• Please keep this product out of reach of children to ensure they are protected from the battery.
• If the battery is accidentally swallowed or enters other parts of the body, seek medical attention immediately. Otherwise, it may cause burns or other dangers inside the body.
• Do not charge the battery. If the battery is low on power, replace it. When replacing the battery, install it according to the correct polarity.
• If the battery leaks, do not allow the skin or eyes to come into contact with the leaked liquid. If it has come into contact with the skin or eyes, immediately rinse with clean water and seek medical attention as soon as possible.
• If the battery needs to be discarded, keep it away from children and recycle or dispose of it in accordance with local laws and regulations.

Quick Installation




Functional Interface Diagram

Power ON/Off	DP Port	Power Port
USB Port	VGA Port	Audio Port
HDMI Port	LAN Port	USB-C Port (Some models only support data transmission)

*The specific interface type shall be subject to the actual configuration of the microcomputer.

Installation of VESA Bracket
Follow the instructions below to install and use the VESA mounting bracket:
1. Fix the two copper screws provided in the packaging box into the corresponding screw holes on the back of the main unit.
2. Use the two black small screws provided in the packing box to fix the VESA bracket to the back of the monitor or TV.
3. Slide the mini main unit into the holes of the VESA mounting bracket through the two screws fixed at the bottom of the main unit to complete the installation.



Warning
Some models do not support VESA bracket installation. Please refer to the actual situation of the product.

Tips and FAQ
1. Turn off your Mini PC
• If your Mini PC does not respond, press the power button for at least (4-6) seconds until your Mini PC is turned off.

2. Boot into the system for the first time
• When you start-up your PC for the first time, you will be guided to configure your Windows operatingsystem.
• Start-up your Mini PC for the first time: Press the PC's power button. Wait for a few minutes until theinstallation interface appears.
Step 1: Select language/country (region)
Step 2: Select the inputting me thod, and clicks confirm
Step 3: Select the second inputting method, which can be "skipped"
Step 4: Networking: After selecting wifi, enter password to connect it, Or choose to plug network cable forconnection. (Networking will be updated automatically, and the update process will stay on an interface fora long time, which prolong the start-up time. (Skipping network connections is strongly recommended)start-up
Step 5: Accept License Agreement
Step 6: Set User Name and Password Once the installation process is complete, the desktop will appear.

3. Connect to Wi-Fi
• Connect Wi-Fi, Connect PC to the Wi-Fi network using the following steps.
• Select the icon from the taskbar.
• Click the wifi icon to turn on the wi-fi.
• Select an access point in the list of available Wi-Fi connections, Select one of the connections to start the network connection.
• Note: You may be prompted to enter a security key to activate a Wi-Fi connection.

4. Enter the BIOS setting
• The BIOS (Basic Input/ Output System) is the first software loaded when the Mini PC starts Enter Bios: Click "Del" or "ESC" key.
• Under normal circumstances, the default BIOS settings apply in most cases to ensure optimum performance. Do not change the default BIOS settings, Except for the following situation.(You have installed new system components that require further BIOS settings or update).

Warning
Inappropriate BIOS settings may cause instability or startup failure. We strongly recommend thatyou can only change the BIOS settings with the help of technical service personnel.

中文

中文

用户指南
尊敬的用户：感谢您使用本产品，为了您的安全和利益请在使用产品之前仔细阅读本产品手册及随机附带的全部资料！

免责声明
• 请务必使用原装电源，对于任何第三方适配器引起的问题或故障，本公司不承担任何责任。
• 用户可以使用第三方提供的音乐、视频、图片和软件，但对于版权问题或软件故障，我们不承担任何责任。
• 如果出现故障，本公司将严格遵守保修条款；但对于使用过程中导致造成的财产损失，本公司不承担任何责任。
• 设备出厂时内置的软件可直接使用。无论是否删除该软件，均不会对机器造成影响，此情况不属于产品质量问题。
• 公司保留对产品进行改进的权利，产品规格和设计如有变更，恕不另行通知!请以实物为准。
• 请勿自行拆解产品，非因产品自身质量问题，而由外部物理或化学损害导致产品损坏的，本公司不承担任何赔偿责任。

注意事项
• 在执行可能造成文件破坏或丢失的操作时，一定要格外小心。
• 在微型计算机使用过程中，要注意对病毒的防护，尽量使用病毒防火墙。
• 如果长时间不使用微型计算机，请将计算机关机，并断开电源。
• 不可短时间频繁开、关微型计算机，两次开机间隔建议不少于60秒。
• 注意防潮，保持使用环境的清洁卫生，若主机上有灰尘，请使用干的软布擦拭。
• 避免强光直接照射到微型计算机上，并不要靠近强磁场。
• 不要将水、食物等流体弄到计算机上，不要用力拉扯数据线、电源线等。

使用条件
• 温度：0~40°C/32~104°F(如温度范围和说明书有冲突，请以说明书为准)。
• 湿度：20~80%RH
• 海拔高度：0~2000米

安全警示
• 本产品内置纽扣电池，禁止拆解、撞击、挤压或投入火中。
• 请勿将本产品置于高温环境中。
• 请将本产品放置在儿童不能接触的地方，以确保儿童远离电池。
• 若电池被误吞或误入体内其他部位，请立即就医，否则将对人体内部造成灼伤或其他危险。
• 禁止对电池充电，如电量不足请更换电池，更换电池时，请按正确的极性安装。
• 若电池漏液，请勿使皮肤或眼睛接触到漏出液体，若已接触到皮肤或眼睛上，请立即用清水冲洗，并寻求医疗。
• 若电池需废弃，请将其远离儿童，并根据当地法律法规回收或处理。

快速安装



功能接口示意图

电源开关	DP接口	电源接口
USB接口	VGA接口	音频接口
高清接口	LAN接口	USB-C接口 (部分机型仅支持数据传输)

*具体接口类型以微型计算机实际配置为准

VESA支架安装
按照以下说明安装和使用VESA安装支架：
• 将包装盒中随附的两个铜制螺丝钉固定在主机背部对应螺孔中。
• 使用包装盒中随附的两个黑色小螺钉，将VESA支架固定到显示器或电视的背面。
• 将迷你主机通过固定在主机底部的两颗螺丝滑入VESA安装支架孔内即可完成安装。



注意
部分型号不支持VESA支架安装，以产品实际情况为准。

提示与常见问题
1. 关闭您的微型计算机
如果您的微型计算机无响应，请按住电源按钮至少 4～6 秒，直到设备关机。

2. 首次启动系统
• 首次启动电脑时，系统将引导您配置 Windows 操作系统。
• 首次启动您的微型计算机：按电脑电源按钮，等待几分钟，直到安装界面出现。
• 步骤 1：选择语言 / 国家（地区）。
• 步骤 2：选择输入法，然后点击确认。
• 步骤 3：选择网络输入方式，可选择 "跳过"。
• 步骤 4：联网：选择 Wi-Fi 后输入密码进行连接，或选择插入网线连接。（系统将自动更新网络组件，更新过程会在某个界面停留较长时间，从而延长启动时间，强烈建议跳过网络连接。）
• 步骤 5：接受许可协议。
• 步骤 6：设置用户名和密码，安装完成后，将进入桌面。

3. 连接 Wi-Fi
• 连接 Wi-Fi，请按以下步骤将计算机连接到 Wi-Fi 网络：
• 从任务栏中选择 Wi-Fi 图标。
• 点击 Wi-Fi 图标开启 Wi-Fi。
• 在可用 Wi-Fi 连接列表中选择一个接入点，建立网络连接。
• 注意：系统可能会提示您输入安全密钥以连接 Wi-Fi。

4. 进入 BIOS 设置
• BIOS（基本输入输出系统）是微型计算机启动时加载的第一个软件。
• 进入 BIOS：按 "DEL" 或 "ESC" 键。
• 在正常情况下，默认的 BIOS 设置可确保最佳性能。请勿更改默认 BIOS 设置，除非出现以下情况：（您已安装新的系统组件，需要进一步设置或更新 BIOS）。

警告
不当的 BIOS 设置可能导致系统不稳定或启动失败。我们强烈建议您在技术服务人员的协助下更改 BIOS 设置。

荷兰语

法语

德语

意大利语

波兰语

西班牙语

瑞典语

韩语

日本语

葡萄牙语

P/N: 1405000433

MADE IN CHINA