




AMBILIGHT tv

Quick Start Guide





90x1 Series



Tool needed for assembly



75"(M5xL18) : x4
85"/100"(M5xL20) : x6



175"85"100"

2

3

A Desk Placement

B Wall Placement

A75"

85"/100"

Recommended Wall Distance

B

	A	B	C	D	E	F	G	H	I	J	K	L	M (kg)	N (kg)
75"	1668.4	953.6	59.4	1263.0	338.4	300	300	684.2	227.3	4xM6	10-12	(K)+★	24.4	25.1
85"	1890.4	1078.2	87.1	1462.8	406.2	600	400	645.2	618.7	4xM8	18-22	(K)+★	29.8	30.6
100"	2227.2	1270.7	89.1	1462.8	406.2	600	500	813.6	711.0	4xM8	18-22	(K)+★	46.0	46.7

(mm)

KG

175"

2

4

Get Connected

www.philips.to/smartTV


The Philips Smart TV app lets you switch channels and adjust the volume - just like a remote control.

5

Register and Support

www.philips.com/tvsupport

Register your TV, find out more, download the user manual and get support



English	Read the safety instructions.	Français	Lisez les consignes de sécurité.	Português	Leia as instruções de segurança.	Türkçe	Güvenlik talimatlarını okuyun.
Български	Прочетете инструкциите за безопасност.	Italiano	Leggere le istruzioni di sicurezza.	Română	Citiți instrucțiunile de siguranță.	Українська	Читайте інструкції з техніки безпеки.
Čeština	Přečtěte si bezpečnostní pokyny.	Қазақша	Қорғаныстық нұсқаулар.	Русский	Читайте инструкции по технике безопасности.	العربية	قراءة تعليمات السلامة.
Hrvatski	Pročitajte sigurnosne upute.	Latviešu	Izlasiet drošības norādījumus.	Srpski	Pročitajte bezbednosna uputstva.	עברית	קראו את הוראות הבטיחות.
Dansk	Læs sikkerhedsforskrifterne.	Lietuvių	Perskaitykite saugos instrukcijas.	Slovenščina	Preberite varnostna navodila.		
Deutsch	Lesen Sie die Sicherheitshinweise.	Magyar	Olvassa el a biztonsági utasításokat.	Slovenský	Prečítajte si bezpečnostné pokyny.		
Ελληνικά	Διαβάστε τις οδηγίες ασφαλείας.	Nederlands	Lees de veiligheidsvoorschriften.	Suomi	Lue turvaohjeet.		
Eesti	Lugege ohutusnõudeid.	Norsk	Les sikkerhetsforskriftene.	Svenska	Läs säkerhetsinstruktionerna.		
Español	Lea las instrucciones de seguridad.	Polski	Zapoznaj się z instrukcjami bezpieczeństwa.	ภาษาไทย	โปรดอ่านคำแนะนำความปลอดภัย.		



1

To install batteries, slide the battery door up.

2

Use 2x AAA (Alkaline) LR03 1.5V (included)

3

Slide battery door back in place.

1 2 3 4

75"/85"/100"

COMMON INTERFACE

USB 2

USB 1

POWER (EU)

POWER (UK)

SAT (EU)

TV ANTENNA

NETWORK

HDMI 1/2

HDMI 3 ARC/eARC

HDMI 4

DIGITAL AUDIO OUT

